

**MEMPHIS SHADES TURN SIGNAL RELOCATION KIT  
MOUNTING INSTRUCTIONS  
MEM9991 AND MEM9992**

**TOOLS REQUIRED:**

**17 MM WRENCH  
PHILLIPS HEAD SCREWDRIVER  
3/16" ALLEN WRENCH**

- 1. REMOVE THE HEADLIGHT LENS FROM THE HEADLIGHT HOUSING. THERE ARE TWO PHILLIPS HEAD SCREWS ON THE SIDE OF THE HOUSING.**
- 2. FOLLOW THE WIRES FROM THE TURN SIGNAL UNTIL YOU FIND THE CONNECTION INSIDE THE HEADLIGHT. UNPLUG THE WIRES (TRY TO DO ONE SIDE AT A TIME OR MARK THE WIRES FOR LEFT AND RIGHT)**
- 3. USING THE 17MM WRENCH, REMOVE THE NUTS FROM THE BACKSIDE OF THE TURN SIGNAL STEMS AND GENTLY PULL THE WIRES THROUGH AND SET THE TURN SIGNAL ASIDE FOR RE-INSTALLATION.**
- 4. INSTALL THE FORK CLAMPS JUST ABOVE THE LOWER TRIPLE TREE (PART THAT HOLDS THE FORKS) WITH THE BLACK ABS TAB FACING FORWARD USING THE 3/16" ALLEN WRENCH.**
- 5. INSTALL THE TURN SIGNALS ONTO THE ABS TABS AND SLIP THE WIRES BACK THROUGH THE REAR OF THE HEADLIGHT HOUSING.**
- 6. RE-PLUG THE WIRES INTO THE PROPER COLOR-CODED LEADS AND RE-INSTALL THE HEADLIGHT LENS.**
- 7. ADJUST THE TURN SIGNALS SO THEY ARE FACING FORWARD AND LEVEL AND TIGHTEN THE NUTS ON THE BACKSIDE.**
- 8. INSTALL THE WINDSHIELD USING THE MOUNTING INSTRUCTIONS PROVIDED WITH THE HARDWARE.**

Memphis Shades warrants all product components, metal and plastic,  
against defects in materials and workmanship for 24 months.

**FOR PARTS AND WARRANTY HELP, CONTACT:**

MEMPHIS SHADES

P.O. Box 429

Rossville, TN 38066

(901) 853-0293

Visit us on the web at [www.memphisshades.com](http://www.memphisshades.com) or

you can also reach us at

customerservice@memphisshades.com

MEM9991MEM9992 01-03-08