

MEMPHIS SHADES TURN SIGNAL RELOCATION KIT
MOUNTING INSTRUCTIONS
MEM9994 FOR KAWASAKI VN750

TOOLS REQUIRED:

PHILLIPS HEAD SCREWDRIVER
3/16" ALLEN WRENCH

1. REMOVE THE HEADLIGHT LENS FROM THE HEADLIGHT HOUSING. THERE ARE TWO PHILLIPS HEAD SCREWS ON THE SIDE OF THE HOUSING.
2. FOLLOW THE WIRES FROM THE END OF THE TURN SIGNAL UNTIL YOU FIND THE CONNECTION INSIDE THE HEADLIGHT. CAREFULLY UNPLUG THE WIRES (TRY TO DO ONE SIDE AT A TIME OR MARK THE WIRES FOR LEFT AND RIGHT)
3. REMOVE THE ALLEN SCREWS THAT HOLD THE TURN SIGNALS ONTO THE MOTORCYCLE. ROTATE THE TURN SIGNALS 90 DEGREES AND PULL THEM OUT OF THE HOLE AND SET THEM DOWN.
4. INSTALL THE FORK CLAMPS JUST ABOVE THE LOWER TRIPLE TREE (PART THAT HOLDS THE FORKS) WITH THE BLACK ABS TAB FACING FORWARD USING THE 3/16" ALLEN WRENCH.
5. INSTALL THE TURN SIGNALS ONTO THE ABS TABS BY PLACING THE TURN SIGNAL THROUGH THE TAB AND ROTATE UNTIL THE 1/4" HOLES ARE ALIGNED. REMOVE THE BEVELED SOCKET WASHER AND 3/8" SCREW MOUNTED ON THE CLAMP.
6. INSTALL THE NEW 3/4" SCREW THROUGH THE BEVELED SOCKET WASHER FOLLOWED BY THE TWO 1/4" HOLES ON THE TURN SIGNAL AND ABS TAB. MOUNT THE TURN SIGNAL ONTO THE CLAMP, MAKING SURE THE TURN SIGNAL IS FACING STRAIGHT FORWARD.

NOTE*-THE ANGLED CUT ON THE REAR ABS TAB IS TO ENSURE PROPER ALIGNMENT

7. RE-PLUG THE WIRES INTO THE PROPER COLOR-CODED LEADS AND RE-INSTALL THE HEADLIGHT LENS.
8. ADJUST THE TURN SIGNALS SO THEY ARE FACING FORWARD AND LEVEL AND TIGHTEN THE NUTS ON THE BACKSIDE.
9. TIGHTEN DOWN THE CLAMPS AND PROCEED WITH THE WINDSHIELD INSTALLATION.

**Memphis Shades warrants all product components, metal and plastic,
against defects in materials and workmanship for 24 months.**

FOR PARTS AND WARRANTY HELP, CONTACT:

MEMPHIS SHADES

P.O. Box 429

Rossville, TN 38066

(901) 853-0293

Visit us on the web at www.memphisshades.com or

you can also reach us at
customerservice@memphisshades.com

MEM9994 01-03-08