



Part No. 2320-0089

MEK1951

REVISION 0

**HD Covered Forks, Without Light Bar  
MS Batwing Fairing and Fats / Slim  
Mounting kit**

**Detachable system allows easy removal.  
Stylish and Functional.**

Before assembly, read Warnings inside



# WARNING


1. During installation, make sure that the fairing / windshield and hardware do not interfere with any cables or wiring when the forks are turned all the way in either direction. Also make sure , through the full range of adjustment, that the fairing / windshield and hardware do not hit the gas tank.
2. This is a detachable fairing / windshield, ALWAYS make sure the locking mechanism is fully engaged after installing the fairing / windshield.
3. The improper installation of this kit and related components could result in serious injury or death.



# CAUTION

1. Memphis Shades fairing / windshields are made from Lucite® acrylic, and will last for years with proper care. Clean your fairing / windshield with plenty of soapy water (mild dishwashing liquid is best) and a soft cotton cloth. Use your bare hands to feel and dislodge bugs, or cover with a wet, soapy towel and let it soak. Don't use paper towels and scrape with anything. Small scratches can be removed with NOVUS #2.
2. Never use any glass cleaning products, petroleum based chemicals, or cleaning agents with ammonia, bleach or any other harsh chemicals. This includes (but not limited to) RainX, brake fluid, acetone, paint thinner, benzene and gasoline. "If it hurts your nose, it will hurt the plastic."
3. Glass cleansing agents will cause severe damage to your fairing / windshield, and will void your warranty.
4. At certain times of the day the Sunlight can reflect off the curvature of a fairing / windshield and cause extreme heat build-up on motorcycle instruments and instrument panel. Take care when parking. Park facing the sun, place an opaque object over the instruments or adjust the fairing / windshield to avoid reflections.

## 1. Kit Contents



Ref	Code	Description	Qty
①	I1951	Mounting Instructions	1
②	M1486	Clutch side mounting plate	1
③	M1487	Throttle side mounting plate	1
④	K26	Upper bushing assembly	2
⑤	K27	Lower bushing assembly	2
⑥	M310	3/16" Short arm allen wrench	1
⑦	R340	1/4" Short arm allen wrench	1

## 2. Mounting Instructions

Additional tools required, that are not included in this kit. 7/16" or 11mm wrench.

**Cover gas tank and front fender with towels to avoid damage during installation.**

1. Locate the upper and lower mounting bolts located on the sides of the front fork covers and remove them along with the Aluminum trim piece. Set the trim piece in a safe place. ***Note: These bolts may be very tight. Take care not to strip the head of the bolts, you may also want to screw the original bolts in and out a few times to clean the threads.***

2. Re-install the Aluminum trim piece using the new bushing assemblies provided in this kit. The upper bolt uses the thicker spacer and the thinner spacer on the lower bolt.

Repeat these steps on the other side. (Fig1)

### 3a. Fit plates to MS Fairing

Install the two mounting plates onto the fairing using the nuts and washers supplied. The small tab goes to the bottom of the fairing, the big one goes to the top. The tabs point in towards the headlight (See Fig 2a).

Continued overleaf.....

Memphis Shades warrants all product components, metal and plastic, against defects in materials and workmanship for 24 months.

### For Parts and Warranty Help, Contact:

Memphis Shades, Inc.

P.O. Box 429

Rossville, TN 38066

(901) 853 0293

Visit us on the web at [www.memphisshades.com](http://www.memphisshades.com) or you can also reach us by email:

[customerservice@memphisshades.com](mailto:customerservice@memphisshades.com)

**HD Covered Forks, Without Light Bar  
MS Batwing Fairing and Fats / Slim  
Mounting kit**

**2. Mounting Instructions, continued**

**3b. Fit plates to MS Fats / Slims**


Install the two mounting plates on the windshield using the bottom and third bolt up. Leave the washers off. The small tab goes to the bottom of the windshield, the big one goes to the top. The tabs point in towards the headlight ( Fig 2b)

4. Slip the mounting plates with the windshield or fairing onto the upper and lower bushing assemblies, and secure the left and right side locking mechanism (Figs 3a/b and 4)

**Note: This is a detachable windshield, ALWAYS make sure the Locking Mechanism is Fully Engaged after installing the windshield! (Fig 5)**

5. Adjust the height, angle and alignment of the windshield or fairing and tighten **ALL** bolts. (Fig 6)


**Fig. 1**




Upper bolt assembly

Lower bolt assembly

**Fig. 2a**




**Fig. 2b**




**Fig. 3a**

Windshield application




**Fig. 3b**

Fairing application




**Fig. 4**



1. Align the plates over the upper and lower bushings.
2. Place the lower slot into the lower bushing.
3. Rotate the top slot into the upper bushing.
4. Engage the trigger lock.

**Fig. 5**



**NOT CORRECT**

**CORRECT**  
**Fully engaged**  
**Locking mechanism**

**Fig. 6**

